



AIRDOPES 170

boat

AIRDOPES 170


Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes 170. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual. Also, you may refer to the same at times when you face any sort of difficulty.

PACKAGE CONTENTS

- 1) 1x Pair of TWS Earbuds
- 2) 1x Charging Case
- 3) 1x Type-C Charging Cable
- 4) 2x Pair of Extra Earmuffs
- 5) 1x User Manual
- 6) 1x Warranty Card
- 7) 1x Catalogue
- 8) 1x FAQ Card

OVERVIEW

- 1) Capacitive Touch Control (CTC)
- 2) Indicator Light
- 3) Charging Port




POWER ON (FIRST TIME USER):

Step 1: To switch the earbuds on (Smart Power On) simply open the lid of the charging case (when earbuds are inside). Courtesy our IWP™ (Insta Wake N' Pair) technology, the earbuds power on automatically, their LEDs begin to flash in blue for 2 seconds, they get connected and enter the connection mode

OR

Long touch the CTC (Capacitive Touch Control) on both earbuds for 3 seconds to manually power on the earbuds

Step 2: After powering on, the earbuds enter the Connection Mode, indicated by LED flashes on the earbuds



CONNECTION MODE:

Step 3: Turn on the Bluetooth functionality on your phone/media device and scan

Step 4: Search for 'Airdopes 170' and pair accordingly.


Congratulations! Your earbuds are now connected successfully via Bluetooth

Note :
 • Pairing mode lasts for 5 minutes. If the pairing time is missed, then you will need to reconnect the earbuds and follow the above-mentioned procedure.
 • Airdopes 170 remembers previously connected devices; once switched on, the earbuds automatically reconnect to the previously connected devices in working range.



QUICK GLANCE ON FUNCTIONALITIES

- 3 Seconds: Long touch the left CTC for 3 sec to activate voice assistant
- 3 Seconds: Long touch both CTCs for 3 seconds to manually power on
- 5 Seconds: Long touch both CTCs for 5 seconds to manually power off
- 5 Seconds: Long touch both CTCs for 5 seconds to perform factory reset



Capacitive Touch Control (CTC)


SINGLE EARBUD USAGE

Step 1: Please note that both the earbuds can be used in mono mode. Use Smart / Manual Power On for switching on the desired earbud

Step 2: The selected earbud automatically enters the connection mode indicated by LED flashes

Step 3: Turn on Bluetooth on your phone/media device and search for 'Airdopes 170' to connect

Notes:
 • To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage
 • You cannot skip tracks or return to the previous tracks in Mono (single-earbud) mode



CHARGING THE EARBUDS

Step 1: Please insert the earbuds back inside the charging case in correct orientation and close the lid

Step 2: Once the earbuds get fully charged, the charging case automatically switches off to save power, and the earbuds' indicator turns off

Notes:
 • Before using the earbuds for the first time, it is recommended to fully charge the earbuds. Also, please keep the lid of the charging case closed while charging.



CHARGE THE CASE:

Step 1: To charge the case, plug one end of the provided cable into the case and connect the other end to a computer/ wall adapter/ powerbank, etc.

White LED blinks continuously while the case is on charging. When the case gets fully charged, it gets indicated by solid white LED.



VOICE ASSISTANT

Step 1: Long touch the CTC on left earbud for 3 seconds to activate default smart voice assistant

Step 2: The respective voice assistant screen pops up and you may place your commands at ease

Tips: You may try out the following commands:
 • What is the weather?
 • Play a song
 • Set a reminder



Note :
 If the voice assistant doesn't get triggered, then the functionality has to be first enabled via your media device settings.

BASIC FUNCTIONS:

- Voice Assistant: Long touch left CTC for 3 seconds to activate your default smart voice assistant
- Answer: Single tap the CTC on either earbud to answer an incoming call
- Hang Up / Reject Call: Double tap the CTC on either earbud to end / reject call
- Play/Pause Music: Single tap either earbud's CTC to play or pause music
- Next Track: When playing music, double tap the right earbud's CTC to skip to the next song
- Previous Track: When playing music, double tap the left earbud's CTC to return to the previous song

Note:
 • Volume can only be controlled via the media device

BEAST™ MODE

Long touch the right CTC for 3 seconds to switch to Low Latency mode, also known as the BEAST™ Mode. Once switched on, it gets notified via a sound prompt. Long touch the right CTC for 3 seconds once again, to turn it off and return to standard Music Mode.

Made for the Gamers - By Gamers, BEAST™ Mode reduces the latency significantly and improves the overall gaming experience.

ENx™ TECH

Our ENx™ (Environmental Noise Cancellation) tech algorithm cancels out the background noise so that you can be heard crystal clear via voice calls. One need not activate ENx™ as the 4x mics are already equipped with the same and activated by default.

Deliver your voice without interruptions anywhere - traffic, railway stations, airports, work space, literally anywhere!

SMART POWER OFF

Step 1: After usage, remove both the earbuds from your ears

Step 2: Place the earbuds back into the charging case in correct orientation and close the lid

The earbuds automatically switch off (and enter charging mode).

MANUAL POWER OFF

Step 1: Long touch both CTCs for 5 seconds to manually power off the earbuds

Step 2: Once the earbuds get turned off, place them back inside the case and close the lid

FACTORY RESET:

Perform the factory reset in case you feel any difficulty while operating your Airdopes.

NOTE: Before performing reset, clear "Airdopes 170" from pairing device history by forgetting device

Step 1: Take out both the earbuds from the charging case

Step 2: Long touch both the CTCs for 5 seconds

Step 3: Place the earbuds back inside the case, close the lid and wait for 5 seconds

Step 4: Take out the earbuds to perform fresh connection

Congratulations! Your Airdopes 170 has been Reset.

Charging norms & Precautionary Guidelines: -

- 1) Charger/Brick/Adapter : 5V 2A
- 2) Cable/Wire : Standard Cable (35 strands @0.10mm diameter/ strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

SPECIFICATIONS

Headphone Type	TWS
Bluetooth Version	V5.3
Music Playtime	Up to 9HRS per charge; Up to 41HRS additional with Case (at 60% volume)
ASAP™ Charge	Yes
Transmission Range	10m
Driver Size	13mm*2
BEAST Mode	50ms
Microphone	4
Bluetooth Profile	SPP/HFP/A2DP/AVCTP
Frequency	20HZ-20KHZ
Battery	470mAh (Case) 40mAh*2 (Earbuds)
Charging Time	2HRS (case); 40min (earbuds)
Charging Interface	USB Type C
Water Resistance	IPX4

WARNING:

- Please follow the instructions to operate
- Please don't use the earbuds in extreme temperatures
- Please don't use the product near water
- Please keep the product away from heat sources, as the heat may damage it
- Don't jam the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life

