

**boat**

**GROOVE THAT SWAYS**

**AIRDOPES 115**

**Airdopes 115**

True Wireless Ear-buds


Get ready to immerse yourself in musical bliss with your very own pair of boat Airdopes 115. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual. Also, you may refer to the same at times when you face any sort of difficulty.

**Package Contents**

- 1 x boat Airdopes 115
- 1 x Charging Case
- 1 x Type-C Charging Cable
- 1 x Pair of Additional Earbuds (Small & Large)
- 1 x User Manual
- 1 x Warranty Card
- 1 x Catalogue

**Overview**

1. CTC (Capacitive Touch Control) / Power Button




**Power On:**

**Step 1:** To switch the earbuds on, insert Power On (single press) into the charging case, remove earbuds and enable Bluetooth on your phone. Keep the earbuds power on automatically, get connected and enter the connection mode.

**OR**

Long touch the CTC (Capacitive Touch Control) earbuds for 3 seconds, to manually power on the earbuds.

**Step 2:** After powering on, the earbuds enter the Connection Mode, indicated by alternate red and blue LED flashes. The secondary earbud will also LED flash when it's ready to be used as the secondary earbud.



**Connection Mode:**


**Step 1:** Turn on the Bluetooth functionality on your phone/mobile device and start.

**Step 2:** Search for Airdopes 115 and pair accordingly.

**Step 3:** Search for Airdopes 115 and pair accordingly.


**Note:**

- Pairing mode lasts for 5 minutes. If the pairing time is interval, then you will need to re-activate the earbuds and follow the same connection procedure.
- Airdopes 115 remembers previously connected devices, once matched on, the earbuds automatically reconnect to the previously connected device at next time usage.



**Quick Guide on Functionalities**

3 Seconds	Long touch left CTC for 3 seconds to activate voice assistant
3 Seconds	Long touch both CTC for 3 seconds to manually power on.
5 Seconds	Long touch either CTC for 5 seconds to manually power off.
5 Seconds	Long touch both CTC for 5 seconds to perform factory reset.



**Single Earbud Usage**


**Step 1:** Please note that both the earbuds can be used to make music. Use Smart Personal Power On to connect on the desired earbud.

**Step 2:** The selected earbud automatically enters the connection mode indicated by LED flash.

**Step 3:** Connect the earbuds on your phone/mobile device and search for Airdopes 115 for pairing.

**Note:**

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud. Hence making Stereo usage.
- This control also tracks or refers to the previous tracks in those single-earbud mode.



**Charge the Earbuds:**


**Step 1:** Please insert the earbuds back inside the charging case in correct orientation and close the lid.

**Step 2:** Once charging, the indicator on the earbuds stop vibrating.

**Step 3:** Once the earbuds fully charged, the charging case automatically switches off to save power, and the earbuds indicate success.

**Note:**

- When using the earbuds for the first time, it is recommended to fully charge the earbuds. Also, please keep the lid of the charging case closed while charging.



**Basic Functions:**

• **Power On/Off:** Long touch the left CTC for 3 seconds to activate the voice assistant.

• **Answer Single:** Tap the CTC on either earbud to answer an incoming call.

• **Hang Up / Power Off:** Double tap the CTC on either earbud to end / reject call.


• **Play/Pause Music:** Single tap either earbud's CTC to play/pause music.

• **Next Track:** When playing music, double tap the right earbud's CTC to skip to the next song.

• **Previous Track:** When playing music, double tap the left earbud's CTC to skip to the previous song.

**Note:**

- Volume can only be controlled via the mobile device.



**Voice Assistant:**


**Step 1:** Long touch the CTC on left earbud for 3 seconds to activate the smart voice assistant.

**Step 2:** The respective voice assistant screen pops up and you may place your commands at ease.

**Tip:** You may try the following commands:

- How's the weather?
- Play a song.
- Set a reminder.

**Note:** If the voice assistant doesn't get triggered, then the functionality has to be first enabled in your mobile device settings.



**BEAST™ Mode**

Long touch the right CTC for 3 seconds to switch to Low Latency mode, also known as the BEAST™ Mode. Once you land on it, you will hear the sound change. Long touch the right CTC for 3 seconds once again, to turn it off and return to Basic Mode.

**Note:** BEAST™ Mode for Games - By Games, BEAST™ Mode reduces the latency significantly and improves the overall gaming experience.

**ENx™ Tech**

The ENx™ tech algorithm can catch up the background noise so that you can be heard better than the voice call. One word, you're "there" as there is equipped with the same and is tested by default.

Before your voice without interruptions anywhere - traffic, safety alarms, airport, noise, you're clearly separated.

**Smart Power Off**

**Step 1:** After usage, remove both the earbuds from your ears.

**Step 2:** Place the earbuds back into the charging case in correct orientation and close the lid. The earbuds automatically switch off and enter charging mode.

**Manual Power Off**

**Step 1:** Long touch both CTC for 5 seconds to manually power off the earbuds.

**Step 2:** Once the earbuds get turned off, place them back inside the case and close the lid.

**Factory Reset:**

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 115.

**NOTE:** Before performing reset, clear Airdopes 115 from pairing device memory by forgetting device.


**Step 1:** Take out both the earbuds from the case.

**Step 2:** Long touch CTC on both the earbuds for 5 seconds, LED flash quickly for 3 times.

**Step 3:** Place the earbuds inside the case, close the lid and wait for 5 seconds.

**Step 4:** Take out the earbuds from the case and perform a fresh connection.

Congratulations! Your Airdopes 115 has been reset.



**Specifications**

Smartphone Type	Android
Bluetooth Version	5.3
Music Playtime	Up to 6HRS per charge, Up to 10HRS with additional USB-C Case (At 80% volume)
Standby Time	110D
Transmittion Range	10m
Driver Size	13mm $\phi$
Bluetooth Profiles	A2DP, AVRCP, HFP, HSP, HSE, HLE, LE Audio, LE Audio LC, LE Audio HC, LE Audio DC, LE Audio BC, LE Audio BC2
Frequency	20Hz-20KHz
Rating	IPX4, Only Water Resistant, Not Waterproof
Charging Time	1.5HRS (Earbuds), 1.5H (Case)
Charging Interface	USB Type-C
Water Resistance	IPX4

**Charging Items & Precaution Guidelines:**

- Charger/Bkls Adapter: Not Available
- Cable/Case: Not Available

Any other accessory can be paired up with the product as long as the specifications are as per device norms.

**Troubleshooting**

Potential Problem	Solution
• Earbuds are not pairing.	• Turn off Bluetooth on your phone
• Earbuds are not charging properly.	• Make sure the earbuds are in the correct orientation in the charging case.
• Earbuds are not working properly.	• Turn off the earbuds and restart them. Then try pairing again.
• Earbuds are not working properly.	• Turn off the earbuds and restart them. Then try pairing again.

**Warning:**

- Please follow the instructions to operate.
- Please don't use the earbuds in extreme temperatures.
- Please don't use the product near water.
- Please keep the product away from heat sources, as this heat may damage it.
- Don't use the ports with a charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume to protect hearing and extend the ear buds service life.

**Note:** The earbuds start at a 100% volume and it may need to be set back when the earbuds are substituted at first. This can be done by using the power/media device.