
# soundcore




Soundcore Sport X10
USER MANUAL

## **Charging**




- Fully dry off the earbuds and the USB port before charging.
- Use a certified USB-C charging cable and charger to prevent any damage.
- Fully charge both the earbuds and the charging case before the first use.
- 1. Place the earbuds in the charging case and close it.
- 2. Connect the charging case to the power supply by using a USB-C charging cable.
- → The LED indicator on the charging case indicates the charging status.



## **Wearing**


- 1. Choose the Ear Tips that fit your ears best.
- 2. Insert the earbuds into the inner canal of your ears and turn gently until you find the most comfortable and secure position.



• Your earbuds come with 5 pairs of Ear Tips, among which Medium-sized are pre-installed.

## **Powering On/Off**


- Open the charging case, the earbuds will automatically power on.
- To power off, place the earbuds into the charging case and close it.



- The earbuds will automatically power off after 10 minutes if no device is connected.
- To manually power on, press and hold the multi-function button on both earbuds for 3 seconds.

## **Bluetooth Pairing**

- 1. Open the charging case, and press the button on the charging case for 3 seconds to enter Bluetooth pairing mode.
  - The 3 LED indicators on the charging case will flash white in sequence continuously.
- 2. Select "Soundcore Sport X10" on your device's Bluetooth list to connect.
  - When successfully connected, the 3 LED indicators will turn white for 3 seconds and then turn off.



- Pairing with another device: Place the earbuds in the charging case and leave the case open. To enter pairing mode, press and hold the button on the case for 3 seconds until the 3 LED indicators flash white in sequence continuously.
- Each time you power on your Soundcore earbuds, they will automatically connect to your last successfully connected device if available within the Bluetooth range.
- Mono mode: When Bluetooth connected, you can use either one of the earbuds only by placing the other one into the charging case.
- When powered on and connected, if either one of the earbuds is out of battery and powered off, you can keep using the other one.
- When you are on a call, place either one of the earbuds into the charging case, and the microphone in the other earbud will be activated.

## **Controls**

#### Stereo Mode

A		
Play/Pause	Press twice (R)	
Next track	Press twice (L)	
Volume up	Press once (R)	
Volume down	Press once (L)	
ANC	Press and hold for 2 seconds(R/L)	

C		
Answer a call	Press once(R/L)	
End a call/Reject a call	Press and hold for 2 seconds(R/L)	

#### Mono Mode

Play/Pause	Press twice
Answer a call	Press once
End a call/Reject a call	
Activate Siri or other voice assistant software	Press and hold for 2 seconds

## **Soundcore App**


Download the Soundcore App to customize the user interface (e.g. adjust volume, control playback, activate Siri), adjust EQ, switch ANC modes, update firmware, and explore more.



### Reset

• You might need to reset the earbuds if you experience any connectivity problems or function issues.

- 1. Place the earbuds in the charging case and leave the case open.
- 2. Press and hold the button on the charging case for 10 seconds until the LED indicators on the case flash white 3 times and then flash in sequence. This confirms that the reset was successful and your earbuds can be connected normally.



# **Specifications**

Specifications are subject to change without notice.

Input	5 V 0.5 A
Rated output power	5 mW (@1% THD)
Battery capacity	55 mAh x 2 (earbuds); 540 mAh (charging case)
Charging time	2 hours
Playtime (varies by volume level and content)	Up to 8 hours (Total 32 hours with the charging case)
Driver size	10 mm x 2
Frequency response	20 Hz - 20 kHz
Impedance	32 Ω
Waterproof level	IPX7(earbuds)
Bluetooth version	5.2
Bluetooth range	10 m / 33 ft