

BLAUPUNKT
TRULY WIRELESS EARBUDS
 BTW



Enjoy it.

Dear customers
 Thank you so much for choosing Blaupunkt high quality True Wireless Earbuds. Please read this instruction manual thoroughly before using this product and keep this manual in a safe place for reference.

Specification

Speaker Driver	φ10mm
Battery specs	Earbuds : 40mAh
	Charging Case: 400mAh
BT Version	5.1
BT profile support	HFP/ HSP/ A2DP/ AVRCP
Bluetooth range	10 m / 33
Frequency response	20 Hz - 20 kHz
Charging time	Approx 2 Hours
Charging Type	Type C

- 1 -

Function operation instructions

Power on : Take the earbuds from the charging case, and turn them on automatically or press or hold the multi-function keys of left and right earbuds for 2 seconds to turn them on

Power off: Put the earbuds into the charging case, and turn them on automatically or press or hold the multi-function keys of left and right earbuds for 4 seconds to shut down. If the earbuds don't paired with the cellphone after starting, it will shut down automatically after 3 minutes.

Reboot: When pairing successfully, the earbuds preferentially enter the connected state. After being turned on a second time, they will automatically connect to the paired device.

Play/Pause : In standby model, click the left and right earbuds multi-function keys to play music directly. When playing, click the left or right earbud's multi-function keys to pause.

Switch Songs : When playing music, press and hold the left earbuds multi-function key until you hear a "deep" sound to switch to the previous song. Press and hold the right earbuds right multi-function keys for 2 seconds until you hear a "deep" sound to switch to the next song.

- 2 -

Volume: Three-Click the left earbuds multi-function key to gradually increase the volume, three-click the right earbuds multi-function key to gradually decrease the volume.

Calls Answering: When your phone rings, click the left or right earbuds multi-function key to answer the call.
 Call Hang up : After your call is complete, click the left or right earbuds multi-function key to hang up the call

Calls Rejected : when your phone rings, hard press your left and right earbud's multi-function keys to reject the call.

Low Battery Prompt : When the battery of your earbuds is low, the low battery tone will be play once every 1 minute until your earbuds are powered off.

- 3 -

Pairing Method:

Common pairing method

1. Take the earbuds from the charging case, or long press the left and right earbuds multi-function keys for 3 seconds to turn on. The red and blue lights flash alternately, enter searching pairing status, headsets pairing automatically. The main headset (left headset) continuously flash red and blue lights alternately after the pairing successfully, the second headset flash blue light slow, at the same time play the sounds of successful pairing.

2. Open the Bluetooth in mobile phone or other devices. If it is Android mobile phone or devices, pls click the optional " Search for Bluetooth device", if it is IOS system mobile phone or device, it will automatically pairing. When search the Bluetooth model No, click to pairing, when the pairing successful, the headset will sound prompt successful connection. The indicators of left and right headphone will turn blue and flash slowly, come into connection standby status, after pairing successful, the right headset is the right channel, and the left headset is the left channel.

3. The headsets also can pair with mobile phone separately. The operation method can refer as above step 2 operation method.

- 4 -

Charing Operation:

1. Plug one end of the USB Type-C charging cable into the USB port of the charging compartment to the charging compartment, the LED will display the latest power.

2. Charge the earphone: Put the earphone into the charging compartment, and it will automatically charged. When charging the indicator light of the earphone is red, and it will go out after being fully charged. The LED light in the charging compartment will display the remaining power. When the headset is fully charged, the LED light in the charging compartment will turn off.

Common troubleshooting:

1. Can't charge the headset when put into the charging case?
 Answer: Whether the earbuds are put into place, whether the charging thimble of the charging case is in good contact with the charging point of the earphones, and whether the surface of the charging thimble and the charging contacts of the earphone are dirty?

2. Only one earphone has sound when connected to the phone?
 Answer: Make sure the earbuds are paired each other before pairing with the phone, otherwise only single earphone is connected to the mobile phone.

- 5 -

Tips :

When you use the Bluetooth headset to listen the music or talk, pls pay attention to adjust the volume properly, so as not to effect the hearing of excessive volume.

Warranty Information 1 Year*

If you have issue with our TWS product please contact our service center Service Centre.

Authorized Service Center Blaupunkt Speakers
 Address: Envent World Wide Pvt Ltd.
 Khasra. No- 15/15(4-16), Village Samalkha, Tehsil Vasant Vihar, New Delhi- 110037 E-Mail: wecare@blaupunktaudio.in
 Tel. 18008434333

Please prepare & submit the following information during the telephone or e-mail notification to facilitate the process:

- Serial Number
- Date of purchase
- A copy of proof of purchase in case of warranty

Note- Important Information
 Please use the original packaging or other suitable packaging to protect the unit in transit.

- 6 -