

STONE 135



LET'S
KEEP ROLLIN'

USER MANUAL

boAt

STONE 135

Thank you for purchasing the boAt Stone 135. You are now just a step away from the realm of pure audio bliss. Please follow this user manual carefully in case of any doubts and difficulties that arise.

Please note that play time will vary depending on the selected volume level. You can stay plugged into the sound with Bluetooth wireless technology, TF and FM mode compatibility. This portable wireless speaker has been designed for smooth interface that requires the minimal of efforts.

Package Contains:

- 1N Portable Bluetooth Speaker
- 1N Micro USB Charging Cable
- 1N User Manual
- 1N Warranty Card
- 1N Catalogue

TWS CONNECTION:

1. Turn the speakers on that you require to be forged into one, both under Bluetooth mode. You need to set up only one of the two units.
2. Double press the MFB on one of the speakers to establish TWS connectivity.
3. A tone gets heard again along with the blue LED turning steady; it may take a few seconds before the two speakers get connected.
4. Activate the phone's Bluetooth and search for "Stone 135" to establish pairing.

TF MODE

- Turn on the speaker
- Insert a Micro SD card in to the TF card slot and it will switch to TF card mode automatically

FM MODE

- Press "+" button and MFB simultaneously to switch to FM mode.
- Under FM mode, long press the "+" and "-" buttons to start scanning the radio stations

NOTE

- You may use the provided USB cable to work as an antenna for clarity in the FM mode.

CHARGING

- Connect one end of the provided charging cable to the charging input and the other end to an adaptor of DC 5V 2A.
- During the charging state, the charging LED indicator is solid red in colour.
 - Once the battery gets fully charged, Charging LED turns off

NOTE

- Please don't use the speaker while it is in charging as it may decrease the battery's performance.

SPECIFICATIONS

Bluetooth Version	v5.0
Net weight	235g
Working range	10m
Driver size	2"
Charging Interface	Micro USB
Water Resistance	IPX4
Standby Time	120H
Frequency Response	180±20%HZ
Compatibility	Bluetooth, TF, FM
Output Power	5W
Charging time	Up to 2.5H
Playing time	Up to 11Hours at 80% volume (playtime varies according to the volume)
Battery	800mAh

Charging Norms & Guidelines: Charger/Adaptor at 5V 2A and Standard Cable (35 strands @0.06mm diameter/strand)

POWER ON/OFF

Long press the MFB (Multi-Function Button) for 3 seconds to switch the speaker on. Similarly, long press the MFB again for 3 seconds to switch the speaker off.



1. Volume up/Next song button
2. MFB Button
3. Volume down/Previous song button
4. Micro USB Charging port
5. TF card slot
6. Mic position

WARNING

- Please keep this product safe from coming in contact with any liquid.
- Don't use/store this product in extreme temperatures.
- Please keep the product away from anything that generates heat, such as radiators, stoves, etc.
- In order to have hearing protection and an extended speaker life, avoid listening to songs on maximum volume.
- Don't try to dismantle / repair the product on your own.



BASIC FUNCTIONS

Power ON	Press and hold the MFB "O" Button for 3 seconds
Power Off	Press and hold the MFB "O" button for 3 seconds
TWS	Dual Press the MFB "O"
Receive a call	Short press MFB "O"
Reject the call	Double press the MFB "O"
Hang up the call	Short press the MFB "O"
Voice Assistant	Triple press the MFB "O"
Volume Up	Short Press "+" button in steps
Next Track	Long press "+" button to skip to the next track
Volume down	Short press "-" button in steps
Previous track	Long press "-" button to go back to the previous track
Play/Pause	Short Press the MFB "O"
Switch Modes	Press "+" button and MFB together to switch to FM mode
Reset	Long press MFB "O" for 8 seconds

NOTE:

- Play time varies according to the level of volume.
- If the speaker doesn't turn off or doesn't respond properly, you could use the Reset functionality.

BLUETOOTH CONNECTIVITY

1. Turn the speaker on and the LED blinks in blue colour
2. Activate the phone's Bluetooth functionality and search for "Stone 135". As soon as the speaker gets selected by you and paired, there comes a sound prompt indicating pairing and the blue LED turns steady

NOTE:

- The speaker can automatically reconnected to the last paired device.
- The speaker gets automatically turned off if there's no pairing established in 10 minutes.

