

boat

MOVE TO THE GROOVE



STONE
Bluetooth Speaker | 90

800 mAh
BATTERY CAPACITY

IPX7
WATER RESISTANT

Neha Kakkar


User Manual

Thank you for purchasing the boAt Stone 190. You are now just a step away from the realm of Nirvana. Please follow this user manual carefully in case of any doubts and difficulties that arise. Please note that play time will vary depending on the selected volume level. You can stay plugged into the sound with Bluetooth wireless technology and aux wire compatibility. This portable wireless speaker has been designed for smooth interface that requires the minimal of efforts. It's time to Plug Into Nirvana.

Package Contents

- 1x Portable Bluetooth Speaker
- 1x Micro USB Charging Cable
- 1x User Manual

1. Lanyard.
2. -: Volume down button: previous song, decrease the volume.
3. Pause button: play, pause, answer call, TWS.
4. +: Volume up button: next song, increase the volume.
5. Power button: power on/off, siri, reset.
6. Mode button: switch the playing mode
7. LED indicator.
8. Micro USB port.
9. AUX IN port
10. Bluetooth indicator.
11. Microphone.



Power ON/OFF

Long press the Power button for 3 seconds to switch the speaker ON. Similarly, long press the Power button for 3 seconds to switch the speaker OFF.

Functions:

- Answer Incoming Calls: Short press the Play/Pause button '▷' once to answer an incoming call
- End Calls: Short press the Play/Pause button '▷' once to end an ongoing call
- Reject Incoming Calls: Long press the Play/Pause button '▷' for 2 seconds to reject an incoming call
- Redial: Double-press the Play/Pause button '▷' to redial the latest called number
- Switch Modes: Short press the 'Mode' button to switch between playing modes: Bluetooth/AUX
- Volume Increase: Short press the "+" button in steps for increasing the volume
- Volume Decrease: Short press the "-" button in steps for decreasing the volume
- Play/Pause: Short press the Play/Pause button '▷' once to play or pause the tracks
- Previous Track: Long press the "-" button for returning to the previous track
- Next Track: Long press the "+" button for skipping to the next track

Note: Play time will vary according to the level of volume.

Bluetooth Connectivity

1. Turn the speaker on and its LED indicator will blink white in colour until the pairing is done
2. Activate the phone's Bluetooth function and search for "boAt Stone 190". As soon as the speaker has been selected by you and paired, there will be a sound prompt indicating pairing and the white LED will turn steady.

Note:

- The speaker can automatically reconnect to the last paired device. If it's not connected, long press the 'Mode' button to connect to the last paired device.
- The speaker gets automatically turned off if there is no pairing for 10 minutes

Disconnecting the Speaker

- For disconnecting the Bluetooth connection, long press the 'Mode' button.

TWS Connection

1. Turn on the two speakers that you require to be forged into one.
2. Long press the Play/Pause button '▷' on one of the speakers for 2 seconds until you hear a sound prompt. This speaker will be the primary speaker of the two.
3. After you release the Play/Pause button '▷', the speakers might take only few more seconds to connect with each other.
4. You can check the indicator lights to distinguish between L/R channels once the speakers are connected. The primary speaker's (left channel) LED will blink with blue colour for every 3 seconds and the secondary speaker's (right channel) LED will show a solid blue colour.

5. You can then connect your phone to the speakers using the Bluetooth functionality.

Disconnecting TWS

- Press and hold the Play/Pause button '▷' on one of the speakers for about 2 seconds until you hear a sound prompt

Charging

- Connect one end of the provided charging cable to the charging input and the other end to a USB adapter/USB port of computer
- During charging, the LED indicator will turn into red; the same will go off as soon as the speaker is fully charged

Note: Please don't use the speaker while it is in charge as it may decrease the battery's performance

Voice Assistant/Siri

- Short press the power button once to activate Siri/Voice Assistant.

Reset Functionality

- Long press the power button for 6 seconds to reset the speaker and turn it off

Note: If the speaker doesn't turn off or doesn't respond, then you can use the Reset functionality.

Specifications:

Bluetooth Version	V5.0
Dimension	100*100*45mm
Net Weight	182 g
Working Range	10m
Driver Size	52mm
Supported Profiles	A2DP, AVRCP, HFP
Waterproof Level	IPX7
Frequency	20Hz-20kHz
Input Voltage	DC 5V/1A
Output Power	5W
Play Time	Up to 4 Hours
Talk Time	Up to 4 Hours
Battery	3.7V / 800mAh

Warning

- Please keep this product safe from coming in contact with any liquid
- Don't use/store this product in extreme temperatures
- Please keep the product away from anything that generates heat, such as radiators, stoves, etc.
- In order to have hearing protection and an extended speaker life, avoid listening to songs on maximum volume
- Don't try to dismantle/repair the product on your own.

MOVE TO THE GROOVE

STONE
Bluetooth Speaker | 90



boat

MOVE TO THE GROOVE



STONE Bluetooth Speaker | 190

800 mAh BATTERY CAPACITY

IPX7 WATER RESISTANT

Neha Kakkar


User Manual

Thank you for purchasing the boAt Stone 190. You are now just a step away from the realm of Nirvana. Please follow this user manual carefully in case of any doubts and difficulties that arise. Please note that play time will vary depending on the selected volume level. You can stay plugged into the sound with Bluetooth wireless technology and aux wire compatibility. This portable wireless speaker has been designed for smooth interface that requires the minimal of efforts. It's time to Plug Into Nirvana.

Package Contents

- 1x Portable Bluetooth Speaker
- 1x Micro USB Charging Cable
- 1x User Manual

1. Lanyard.
2. -: Volume down button: previous song, decrease the volume.
3. Pause button: play, pause, answer call, TWS.
4. +: Volume up button: next song, increase the volume.
5. Power button: power on/off, siri, reset.
6. Mode button: switch the playing mode
7. LED indicator.
8. Micro USB port.
9. AUX IN port
10. Bluetooth indicator.
11. Microphone.



Power ON/OFF

Long press the Power button for 3 seconds to switch the speaker ON. Similarly, long press the Power button for 3 seconds to switch the speaker OFF.

Functions:

- Answer Incoming Calls: Short press the Play/Pause button '▷' once to answer an incoming call
- End Calls: Short press the Play/Pause button '▷' once to end an ongoing call
- Reject Incoming Calls: Long press the Play/Pause button '▷' for 2 seconds to reject an incoming call
- Redial: Double-press the Play/Pause button '▷' to redial the latest called number
- Switch Modes: Short press the 'Mode' button to switch between playing modes: Bluetooth/AUX
- Volume Increase: Short press the "+" button in steps for increasing the volume
- Volume Decrease: Short press the "-" button in steps for decreasing the volume
- Play/Pause: Short press the Play/Pause button '▷' once to play or pause the tracks
- Previous Track: Long press the "-" button for returning to the previous track
- Next Track: Long press the "+" button for skipping to the next track

Note: Play time will vary according to the level of volume.

Bluetooth Connectivity

1. Turn the speaker on and its LED indicator will blink white in colour until the pairing is done
2. Activate the phone's Bluetooth function and search for "boAt Stone 190". As soon as the speaker has been selected by you and paired, there will be a sound prompt indicating pairing and the white LED will turn steady.

Note:

- The speaker can automatically reconnect to the last paired device. If it's not connected, long press the 'Mode' button to connect to the last paired device.
- The speaker gets automatically turned off if there is no pairing for 10 minutes

Disconnecting the Speaker

- For disconnecting the Bluetooth connection, long press the 'Mode' button.

TWS Connection

1. Turn on the two speakers that you require to be forged into one.
2. Long press the Play/Pause button '▷' on one of the speakers for 2 seconds until you hear a sound prompt. This speaker will be the primary speaker of the two.
3. After you release the Play/Pause button '▷', the speakers might take only few more seconds to connect with each other.
4. You can check the indicator lights to distinguish between L/R channels once the speakers are connected. The primary speaker's (left channel) LED will blink with blue colour for every 3 seconds and the secondary speaker's (right channel) LED will show a solid blue colour.

5. You can then connect your phone to the speakers using the Bluetooth functionality.

Disconnecting TWS

- Press and hold the Play/Pause button '▷' on one of the speakers for about 2 seconds until you hear a sound prompt

Charging

- Connect one end of the provided charging cable to the charging input and the other end to a USB adapter/USB port of computer
- During charging, the LED indicator will turn into red; the same will go off as soon as the speaker is fully charged

Note: Please don't use the speaker while it is in charge as it may decrease the battery's performance

Voice Assistant/Siri

- Short press the power button once to activate Siri/Voice Assistant.

Reset Functionality

- Long press the power button for 6 seconds to reset the speaker and turn it off

Note: If the speaker doesn't turn off or doesn't respond, then you can use the Reset functionality.

Specifications:

Bluetooth Version	V5.0
Dimension	100*100*45mm
Net Weight	182 g
Working Range	10m
Driver Size	52mm
Supported Profiles	A2DP, AVRCP, HFP
Waterproof Level	IPX7
Frequency	20Hz-20kHz
Input Voltage	DC 5V/1A
Output Power	5W
Play Time	Up to 4 Hours
Talk Time	Up to 4 Hours
Battery	3.7V / 800mAh

Warning

- Please keep this product safe from coming in contact with any liquid
- Don't use/store this product in extreme temperatures
- Please keep the product away from anything that generates heat, such as radiators, stoves, etc.
- In order to have hearing protection and an extended speaker life, avoid listening to songs on maximum volume
- Don't try to dismantle/repair the product on your own.

MOVE TO THE GROOVE

STONE Bluetooth Speaker | 190



boat

MOVE TO THE GROOVE

STONE
Bluetooth Speaker | 90

800 mAh
BATTERY CAPACITY

IPX7
WATER RESISTANT

Neha Kakkar


User Manual

Thank you for purchasing the boAt Stone 190. You are now just a step away from the realm of Nirvana. Please follow this user manual carefully in case of any doubts and difficulties that arise. Please note that play time will vary depending on the selected volume level. You can stay plugged into the sound with Bluetooth wireless technology and aux wire compatibility. This portable wireless speaker has been designed for smooth interface that requires the minimal of efforts. It's time to Plug Into Nirvana.

Package Contents

- 1x Portable Bluetooth Speaker
- 1x Micro USB Charging Cable
- 1x User Manual

1. Lanyard.
2. -: Volume down button: previous song, decrease the volume.
3. Pause button: play, pause, answer call, TWS.
4. +: Volume up button: next song, increase the volume.
5. Power button: power on/off, siri, reset.
6. Mode button: switch the playing mode
7. LED indicator.
8. Micro USB port.
9. AUX IN port
10. Bluetooth indicator.
11. Microphone.



Power ON/OFF

Long press the Power button for 3 seconds to switch the speaker ON. Similarly, long press the Power button for 3 seconds to switch the speaker OFF.

Functions:

- Answer Incoming Calls: Short press the Play/Pause button '▷' once to answer an incoming call
- End Calls: Short press the Play/Pause button '▷' once to end an ongoing call
- Reject Incoming Calls: Long press the Play/Pause button '▷' for 2 seconds to reject an incoming call
- Redial: Double-press the Play/Pause button '▷' to redial the latest called number
- Switch Modes: Short press the 'Mode' button to switch between playing modes: Bluetooth/AUX
- Volume Increase: Short press the "+" button in steps for increasing the volume
- Volume Decrease: Short press the "-" button in steps for decreasing the volume
- Play/Pause: Short press the Play/Pause button '▷' once to play or pause the tracks
- Previous Track: Long press the "-" button for returning to the previous track
- Next Track: Long press the "+" button for skipping to the next track

Note: Play time will vary according to the level of volume.

Bluetooth Connectivity

1. Turn the speaker on and its LED indicator will blink white in colour until the pairing is done
2. Activate the phone's Bluetooth function and search for "boAt Stone 190". As soon as the speaker has been selected by you and paired, there will be a sound prompt indicating pairing and the white LED will turn steady.

Note:

- The speaker can automatically reconnect to the last paired device. If it's not connected, long press the 'Mode' button to connect to the last paired device.
- The speaker gets automatically turned off if there is no pairing for 10 minutes

Disconnecting the Speaker

- For disconnecting the Bluetooth connection, long press the 'Mode' button.

TWS Connection

1. Turn on the two speakers that you require to be forged into one.
2. Long press the Play/Pause button '▷' on one of the speakers for 2 seconds until you hear a sound prompt. This speaker will be the primary speaker of the two.
3. After you release the Play/Pause button '▷', the speakers might take only few more seconds to connect with each other.
4. You can check the indicator lights to distinguish between L/R channels once the speakers are connected. The primary speaker's (left channel) LED will blink with blue colour for every 3 seconds and the secondary speaker's (right channel) LED will show a solid blue colour.

5. You can then connect your phone to the speakers using the Bluetooth functionality.

Disconnecting TWS

- Press and hold the Play/Pause button '▷' on one of the speakers for about 2 seconds until you hear a sound prompt

Charging

- Connect one end of the provided charging cable to the charging input and the other end to a USB adapter/USB port of computer
- During charging, the LED indicator will turn into red; the same will go off as soon as the speaker is fully charged

Note: Please don't use the speaker while it is in charge as it may decrease the battery's performance

Voice Assistant/Siri

- Short press the power button once to activate Siri/Voice Assistant.

Reset Functionality

- Long press the power button for 6 seconds to reset the speaker and turn it off

Note: If the speaker doesn't turn off or doesn't respond, then you can use the Reset functionality.

Specifications:

Bluetooth Version	V5.0
Dimension	100*100*45mm
Net Weight	182 g
Working Range	10m
Driver Size	52mm
Supported Profiles	A2DP, AVRCP, HFP
Waterproof Level	IPX7
Frequency	20Hz-20kHz
Input Voltage	DC 5V/1A
Output Power	5W
Play Time	Up to 4 Hours
Talk Time	Up to 4 Hours
Battery	3.7V / 800mAh

Warning

- Please keep this product safe from coming in contact with any liquid
- Don't use/store this product in extreme temperatures
- Please keep the product away from anything that generates heat, such as radiators, stoves, etc.
- In order to have hearing protection and an extended speaker life, avoid listening to songs on maximum volume
- Don't try to dismantle/repair the product on your own.

MOVE TO THE GROOVE

STONE
Bluetooth Speaker | 90

