

Manual

Thank you for purchasing the boAt Stone 580. You are now just a step away from the realm of pure audio bliss. Please follow this user manual carefully in case of any doubts and difficulties that arise.

Please note that play time will vary depending on the selected volume level. You can stay plugged into the sound with Bluetooth wireless technology, AUX, USB and FM mode compatibility. This portable wireless speaker has been designed for smooth interface that requires the minimal of efforts.




PACKAGE CONTENTS

- 1 x Stone 580
- 1 x Manual
- 1 x USB Type C charging Cable
- 1 x Warranty Card
- 1 x Catalogue

PACKAGE CONTENTS

- ① Type-C Charging Jack
- ② AUX Port
- ③ USB Port
- ④ Backward/Volume Down
- ⑤ Forward/Volume Up
- ⑥ Mode/TWS Button
- ⑦ Play/Pause & Voice Assistant Button
- ⑧ RGB Light
- ⑨ Power Button



FEATURES:

- 2.0CH portable Bluetooth speaker
- TWS function, achieve true wireless playing with double enhanced stereo sound
- Optimized voice assistant control
- Hands-free Mic for hands-free calling
- Three different modes of RGB Lighting
- With A2DP Bluetooth, wireless stream music from any Bluetooth-enabled device
- USB support
- FM radio
- Line-in function, suitable for PC, MID, TV and other audio devices
- Built-in lithium rechargeable battery 2000mAh

POWER ON/OFF

Long-press the Power button to turn the speaker on and off.

BLUETOOTH:

- Turn the power button to "ON". The speaker enter Bluetooth mode automatically.
- Activate Bluetooth of mobile phone and search for device name "Stone 580" then connect it.



Front

- Play the music from your mobile phone and enjoy.
- Long-press Forward or Backward button to select songs.
- Short-press Forward or Backward button to adjust volume up & down.
- Short-press Play/Pause button to play/pause the music.
- Long-press the RGB Light button to disconnect the Bluetooth connection with the mobile device.

TWS FUNCTION:

- Turn on two identical speakers you want to pair, both under BT mode. Only need to set one of the two units.
- Long-press the TWS button to pair, speaker will make a tone to start to pair, and make a tone again after paired successfully.
- Make Bluetooth connection with your mobile phone to play music by the two paired Speakers.
- Long-press the TWS button again to exit TWS function.

PLAYING MUSIC FROM USB DISK:

- Turn the Power button to "ON".
 - Insert USB flash disk into slot, the speaker will play the stored music automatically.
 - Long-press Forward or Backward button to select songs you like, short-press to adjust the volume up and down.
 - Short-press Play/Pause to play or pause.
- Notes: Under any playing mode, when you insert a USB disk to the speaker, it will switch to play the USB disk.

RGB LIGHT:

The RGB light is on when speaker powered on, user can short-press the RGB Light button to turn the three different light modes and turn it off.

FM RADIO:

- Under FM radio state, the charging cable provided treat as antenna, please insert the charging cable to the charging port before using.
- Turn the power button to "ON", short-press the "MODE" button to enter radio state.
- Short-press "Play/Pause" button to mute the speaker. Long-press "Play/Pause" button to auto search the FM Channel and store it automatically.
- Long-press Forward or Backward button to change the stored FM channel, short-press to adjust the volume up and down.

AUX-IN:

- For other compatible music devices, use an audio line cable to connect from the device's "Line Out" to the "Aux In" of this device, then enjoy...
- Under any playing mode, when you use the audio cable to connect the device, it will auto-switch to the AUX mode.
- When using an external device, all functions can be controlled by the external device.

ACTIVATING VOICE ASSISTANT:

- Make Bluetooth connection with your mobile phone.
- Long-press Voice Assistant button to activate voice assistant.

HANDS-FREE CALL:

- Under Bluetooth connection status, if there is an incoming call, user can short-press Play/Pause button to accept the call or long-press Play/Pause button to reject the call.
- During the call, user can long-press Play/Pause button to switch to talking on the phone.
- Short-press Play/Pause button or operate on mobile phone to end the call.

RESET FUNCTIONALITY:

If the speaker does not turn off or respond, user can short-press the RESET button in Aux Port with a small round pin.

HOW TO CHARGE:

- The charger is not included in the package, please charge this speaker via a standard 5V/1-3A charger or via a PC.
- Charge time should be 3 hours. Once the speaker is full charged, the charging indicator will be off.
- The unit does not have power bank function, it is forbidden to charge other device via this unit or to connect other device via the USB port.
- To protect the battery, please do not use the speaker while it is charging.

SPECIFICATIONS

Bluetooth version:	V5.1
Speaker Size:	2 inch*2
Output:	12W
Battery Capacity:	3.7V, 2000mAh
Play time:	3 hours at maximum volume & 7 hours at 50% volume
Frequency Response:	80HZ-20KHZ
BT connecting range:	10m
Product size:	255(L)*87(W)*110(H)MM

MORE REMARKS:

- Default volume is at 50% status of max volume.
- Play time may vary depending on volume level and music style.

WARNING:

- Please store and use this product in an environment of normal temperature.
- Please do not expose this product to rain or moisture environment.
- Please do not disassemble, repair or modify this product by yourself without authorization.
- When cleaning this product, please use a soft cloth or with little water if needed, please do not use chemicals for cleaning.
- In order to have an extended product life and protect your hearing, please avoid listening to songs on maximum volume for long time.
- The product is with built-in lithium battery, to avoid dangers, please do not discard or put it in the fair.

Charging norms & Precautionary Guidelines: -

1) Charger/Brick/Adapter	: 5V 2A
2) Cable/Wire	: Standard Cable (35 strands @0.10mm diameter/ strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

Back