



boat

Thank you for purchasing the boAt Stone 500. You are now just a step away from the realm of pure audio bliss. Please follow this user manual carefully in case of any doubts and difficulties that arise. Please note that play time will vary depending on the selected volume level. You can stay plugged into the sound via Bluetooth wireless technology, USB, AUX or FM compatibility. This portable wireless speaker has been designed for smooth interface that requires the minimal of efforts.

PACKAGE CONTAINS:

- 1X Portable Bluetooth Speaker
- 1X User Manual
- 1X Type-C Charging Cable
- 1X Warranty Card
- 1X Audio Cable
- 1X Catalogue

USER MANUAL

TWS CONNECTION

1. Turn the speakers on that you require to be forged into one, both under Bluetooth mode. You need to set up only one of the two units.
2. Long press the Mode button of one of the speakers; a sound is heard confirming the TWS pairing.
3. During pairing of the two speakers, the host speaker's LED remains solid blue while the secondary speaker's LED flashes in blue for 5 seconds. Once they get paired, secondary speaker's LED turns into solid blue.
4. After a few seconds when the two speakers get paired with each other, open the phone's Bluetooth settings and search for "Stone 500".

Note

Long press the Mode button if you want to disconnect the TWS functionality

AUX MODE

- Turn on the speaker
- Connect the speaker to your media device via the provided AUX cable and start the playback.

USB MODE

- Turn on the speaker
- Insert the USB media storage device into the USB port on the speaker
- Playback starts automatically

FM MODE

- Insert the charging cable into the charging port, which acts as a receiving antenna
- Use the Mode button to change the playback mode to FM
- Short press the Power button to start auto scanning the radio stations
- Once the scan is complete, you can long press the +/- button to change the stations

CHARGING

Connect one end of the provided charging cable to the charging input and the other end to an adaptor of DC 5V 2A.

- During the charging state, the charging LED indicator is solid red in colour.
- Once the battery gets fully charged, Charging LED turns off

Note


- Please don't use the speaker while it is in charging as it may decrease the battery's performance.
- The unit does not have power bank function, the USB port is only for music playback. It's forbidden to charge other device via this unit or to connect other device via a USB cable.

SPECIFICATIONS

Speaker Type	Portable Stereo
Bluetooth Version	v5.0
Net weight	0.65kg
Working range	10m
Driver size	50mm x 2
Bluetooth Profile	a2dp/avctp/avdtp/lavcsp/hfp/lpp/smp/att/gatt/rfcomm/udp/l2cap profile
Charge Interface	USB Type C
Frequency Response	100Hz to 12KHz
Input Voltage	DC 5V/2A
Output Power	10W RMS
Charging time	Up to 2 HRS
Playing time	5HRS w/o RGB; 4HRS w/ RGB at 60% volume (playtime will vary according to the volume)
Battery	1200mAh

Charging Nozzle & Guidelines: Charger Adapter @ 5V 2A and Standard Cable (US standard @ 0.05mm diameter) (noted)

PRODUCT DETAILS



Power ON/OFF

Long press the power button for 2 seconds to switch the speaker ON. Similarly, long press the Power button again for 2 seconds to switch the speaker off.

BASIC FUNCTIONS

ITEMS	INSTRUCTIONS
Answer Incoming Calls	Short press Power button "O" once to answer an incoming call.
Reject Incoming Calls	Long press Power button "O" for 2 seconds to reject an incoming call.
End Calls	Short press Power button "O" or operate on phone to end the call.
Volume Up	Short press the "+" button in steps for increasing volume.
Volume Down	Short press the "-" button in steps for decreasing volume.
Next Song	Long press "+" button for 2 seconds.
Last Song	Long press "-" button for 2 seconds.

Play/Pause	Short press the Power button "O"
Voice Assistant	Double press the Mode button "M"
RGB LEDs On/Off	Press "+" & "-" buttons together to turn On/Off the RGB LEDs; Default mode - RGB on
Mode Switch	Short press Mode Button "M" to switch among play/bank modes; the sequence being BT/FM/USB/AUX IN.
Switch Calls between Speaker & Phone	During an ongoing call, long press the Power button "O" for 2 seconds.
Reset	Press Mode Button "M" & volume down "-" together to reset

Note:

• Playtime varies according to the level of volume.

BLUETOOTH CONNECTIVITY

1. Turn the speaker on and the LED blinks in blue
2. Activate the phone's Bluetooth functionality and search for "Stone 500". As soon as the speaker gets selected by you and paired, there comes a sound prompt indicating pairing and the blue LED turns steady



Note

- The speaker can automatically reconnect to the last paired device.
- The speaker gets automatically turned off if there's no pairing established in 10 minutes.

WARNING

- Please keep this product safe from coming in contact with any liquid.
- Don't use/store this product in extreme temperatures.
- Please keep the product away from anything that generates heat, such as radiators, stoves, etc.
- In order to have hearing protection and an extended speaker life, avoid listening to songs on maximum volume.
- Don't try to dismantle / repair the product on your own.

