

Slay
While You Move



Manual Setup Guide

Airdopes 621

Twin Wireless Ear-buds

Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes 621.

Please consider this manual as your guiding map towards the unparalleled shores of musical bliss.

Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.

In the box

- 1 1x Pair of TWS Earbuds
- 2 1x Charging Case
- 3 2x Pairs of Additional Earmuffs
- 4 1x Type-C Charging Cable
- 5 1x User Manual
- 6 1x Warranty Card
- 7 1x Catalogue

Power On (First Time User)

Step 1: To switch the earbuds on (Smart Power On) simply open the lid of the charging case (when earbuds are inside). Our IWP™ (Insta Wake N' Pair) Technology enables the earbuds to power on automatically, get connected and enter into the connection mode

OR
Long touch the CTC on both earbuds for 3 seconds to manually power on the earbuds

Step 2: Both the earbuds will automatically pair with each other. The earbuds will enter into the Connection Mode, indicated by green LED flashes

Connection Mode


Step 3: Turn on the Bluetooth functionality on your phone/media device and scan

Step 4: Search for 'Airdopes 621' and pair accordingly.

Congratulations! Your earbuds are now connected successfully via Bluetooth

Note: Pairing mode lasts for 5 minutes. If the pairing time is missed then you will need to reconnect the ear-buds and follow the above mentioned procedure

Airdopes 621 remembers previously connected devices; once switched on, the ear-buds automatically reconnect to the previously connected devices



Single Earbud Usage

Step 1: Please note that both the earbuds can be used in mono mode. Use Smart / Manual Power On for switching on the desired earbud

Step 2: The selected earbud will automatically enter the connection mode indicated by green LED flashes

Step 3: Turn on Bluetooth on your phone/media device and search for 'Airdopes 621' to connect

Notes:

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage
- You cannot skip tracks or return to the previous tracks in Mono mode



LED Indicators / Functionalities

2 Seconds

Long touch either CTC for 2 sec to activate voice assistant

3 Seconds

Long touch both CTCs for 3 seconds to manually power on

5 Seconds

Long touch either CTC for 5 seconds to manually power off

10 Seconds

Long press the CTC on both earbuds inside the case for up to 10 seconds for reset



Charging The Earbuds


Step 1: Please insert the earbuds back inside the charging case in correct orientation.

Step 2: A solid green LED indicates that the earbuds are being charged. Once fully charged the LED turns off

Step 3: Once the earbuds are fully charged, the charging case automatically switches off to save power.

Note:

- Before using the ear-buds for the first time, it is recommended to fully charge the ear-buds. Also, please keep the lid of the charging case closed while charging



Charge The Case

Step To charge the case, plug one end of the provided cable into the case and connect the other end to a computer/ wall adapter/ powerbank, etc. The case battery display shows the remaining battery capacity of the case as well as of both the earbuds



Basic Functions

- Voice Assistant: Long touch the CTC on either earbud for 2 seconds to activate the voice assistant
- Answer/Hang Up Call: Single tap the CTC on either earbud to answer an incoming call and once again to hang up an ongoing call
- Reject Call: Long touch the CTC for up to 1.5 seconds to reject incoming calls
- Play/Pause Music: Single tap on either earbud's CTC to play or pause music
- Next Track: When playing music, double tap the right CTC to skip to the next song
- Previous Track: When playing music, double tap the left CTC to return to the previous song
- Powerbank Function: In case of emergency, for instance when your phone runs out of battery, you may utilize the 2600mAh Case for charging your device for some time

Note:

- It is advisable not to use the Carry cum Charge case as a power bank unless there's some sort of emergency
- Volume can only be controlled via the media device. The earbuds do not support this function

Voice Assistant

Step 1: Long touch the CTC on either earbud for 2 seconds to activate the smart voice assistant (Google/Siri Assistant)

Step 2: The respective voice assistant screen pops up and you may place your commands at ease

Tips: You may try the following commands,

- What is the weather?
- Play a song
- Set a reminder



Smart Power Off

Step 1: After usage, remove both the earbuds from your ears

Step 2: Place the earbuds back into the charging case in correct orientation

Step 3: The earbuds will automatically switch off (and enter into charging mode)

Manual Power Off

Step 1: Long touch the CTC on either earbud for 5 seconds

Step 2: Once the earbuds get turned off, place them back inside the case and close the lid



Factory Reset

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 621

*NOTE: Before performing reset, clear "Airdopes 621" from pairing device history by forgetting device

Step 1: Place both the earbuds back inside the charging case in correct orientation

Step 2: Long press the CTC on both earbuds inside the case for up to 10 seconds to do Factory reset, which is indicated by the flashing of green LED three times

Step 3: Shut the lid of the charging case and then re-open it again

Step 4: Once you take the earbuds out from the charging case, they automatically restart

Step 5: Congratulations! Your Airdopes 621 has been Reset



Troubleshooting

Potential Problem	Solution
If one earbud is not working	Perform the Factory Reset
If earbuds are not in connection/ scan mode	Perform the Factory Reset
If earbuds disconnect during phone call	Charge the earbuds or perform the Factory Reset
If there are other exceptions in usage	Place the earbuds back into the charging case and try using them again or perform the Factory Reset
If the In-Ear Detection or Touch Controls don't seem to respond	After long usage, residual stains and perspiration can affect the touch control area, please use a clean cloth to wipe those areas softly

Charging norms & Precautionary Guidelines:

1) Charger/Brick/Adapter	: 5V/2A
1) Cable/Wire	: Standard Cable (35 Strands @0.10mm diameter/strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

Specifications

Bluetooth Version	V5.0
Water Resistance	IPX7
IWP Technology	Yes
Power Bank Function	Yes
Music Playtime	Up to 5.5H per charge; Up to 150H additional with Case
Standby Time	70H
Transmission Range	10m
Driver Size	6mm*2
Bluetooth Profiles	HFP/ HSP/ A2DP/ AVRCP
Frequency	20Hz-20KHz
Battery	2600mAh (Case) 35mAh*2 (Earbuds)
Charging Time	About 45mins Earbuds; 3-4 hours Case
Charging Interface	Type C
Product Weight	129g

Warning

- Please follow the instructions to operate
- Please don't use the ear-buds in extreme temperatures
- Please don't use the product near water
- Please keep the product away from heat sources, as the heat may damage it
- Don't jam the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life

Advisable: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first. This can be done by using the phone / media device.

Slay
While You Move



Airdopes 621
Twin Wireless Ear-buds