



Airdopes 111

True Wireless Ear-buds

Get ready to immerse yourself in musical bliss with your very own pair of boat Airdopes 111. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.

Package Contents

- 1 In Both Airdopes 111
- 1 Charging Case
- 1 In-Type-C Charging Cable
- 2 In Pair of Additional Earbuds (Small & Large)
- 1 User Manual
- 1 Warranty Card
- 1 Garbage

Overview

- 1 CTC (Capacitive Touch Control) / Power Button




Power On:

Step 1: To switch the earbuds on, SmartPower™ simply opens the lid of the charging case. When earbuds are ready, the LED™ (Small & Large) Technology enables the earbuds to power on automatically, get connected and enter into the connection mode.

OR

Step 2: After powering on, the earbuds enter into the Connection Mode indicated by red and blue LED™.



Connection Mode:

Step 3: Turn on the Bluetooth functionality on your phone/mobile device and start.

Step 4: Search for the Airdopes 111 and pair accordingly.


Important: Your earbuds are now connected successfully on Bluetooth.

Note:

- 1 Pairing mode lasts for 3 minutes. If the pairing time is over then you will need to re-pair the earbuds with the phone/mobile device.
- 2 Airdopes 111 earbuds are previously connected device once established on the earbuds automatically reconnect to the previously connected device.



LED Indicators / Functionalities



Single Earbud Usage

Step 5: Please note that both the earbuds can be used as stereo mode. Use Smart™ (Small & Large) Tech for switching on the selected earbud.

Step 6: The selected earbud will automatically enter the connection mode indicated by red and blue LED™.

Step 7: Turn on the earbuds on your phone/mobile device and search for Airdopes 111 to connect.

Note:

- 1 If you wish to use stereo mode, simply take out the other earbud from the case and will automatically power on and pair with the previously selected earbud. Please ensure stereo mode.
- 2 This cannot be used in stereo mode in previous buds in stereo mode.



Charge the Earbuds:

Step 1: Please insert the earbuds inside their charging case to connect them.

Step 2: The red LED™ on earbuds indicates that the earbuds are being charged. Once fully charged the LED™ turns off.

Step 3: Close the earbuds on fully charged, the charging case automatically switches off the red LED™.

Note:

- 1 Before using the earbuds for the first time, it is recommended to fully charge the earbuds. Also, please keep the lid of the charging case closed while charging.
- 2 Battery is 30% or below that the red LED™ blinks every five seconds to indicate the state.

Charge the Case:

Step 1: To charge the case, plug one end of the provided cable into the case and connect the other end to a computer wall adapter powerbank etc.

The LED™ flashes while the case is in charging. When the charge gets full, it gets indicated by solid red LED™.



Basic Functions:

- 1 When you don't long touch the CTC on either earbud for 3 seconds to activate the voice assistant.

- 2 Answer: Single tap the CTC on either earbud to answer an incoming call.

- 3 Hang Up / Repeat Call: Double tap the CTC on either earbuds and an repeat call.

- 4 Play/Pause Music: Single tap on either earbud's CTC to play or pause music.

- 5 Next Track: When playing music, double tap the right CTC to skip to the next song.

- 6 Previous Track: When playing music, double tap the left CTC to return to the previous song.

Note:

- 1 Volume can only be controlled via the media device.



Voice Assistant:

Step 1: Long touch the CTC on either earbud for 3 seconds to activate the smart voice assistant.

Step 2: The interactive voice assistant screen pops up and you may place your commands at ease.

Note: You may try by the following commands.

- 1 What is the weather?

- 2 Play a song

- 3 Set a reminder



Smart Power Off

Step 1: After usage, remove both the earbuds from your ears.

Step 2: Place the earbuds back into the charging case in correct orientation and close the lid.

The earbuds will automatically switch off and enter into charging mode.



Manual Power Off

Step 1: Long touch both CTC for 5 seconds to manually power off.

Step 2: Once the earbuds get turned off, place them back inside the case and close the lid.

Factory Reset:

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 111.

Note: Before performing reset, clear "Airdopes 111" from pairing device history by forgetting device.

Step 1: Take out the earbuds from the charging case and long touch the CTC for 5 seconds on both the earbuds, indicated by LED™ for 5 times.

Step 2: Place the Earbuds back inside the Case, close the Lid and wait for 5 sec.

Step 3: Take out the earbuds from the charging case and perform a fresh connection.

Step 4: Congratulations! Your Airdopes 111 has been reset.



Specifications

Bluetooth Version	BLE 5.0
IPX7 Technology	Yes
Music Playback	Up to 1hr per Charge (Up to 2.5hr additional with Case)
Talk Time	10
Transmission Range	10m
Driver Size	10mm
Bluetooth Profiles	HSP, HFP, A2DP, AVRCP
Frequency	2400 - 2480MHz
Battery	100mAh (Case), 40mAh (2 Earbuds)
Earbuds Weight	18
Case Charging Time	1.5hr
Charging Interface	Type-C
Product Weight	Earbuds 2.1g, Case 40.0g

Charging Items & Precautionary Guidelines:	
1) Charger/Built-in Adapter	10W/20W
2) Cable/Wire	Supports USB-C (A) 1.1 or USB-C (A) 2.0 (Type-A) standard

Any other accessories can be paired up with this product as long as the specifications are as per device norms.

Troubleshooting

Potential Problem	Solution
1) No sound in either earbud	1) Make sure you are wearing the earbuds correctly.
2) Earbuds are not in connection mode	2) Make sure you have turned on the Bluetooth on your phone.
3) Earbuds disconnected during use	3) Close the earbuds in either the charging case.
4) Not in pairing mode	4) Place the earbuds back into the charging case and long touch the CTC for 5 seconds to enter into pairing mode.
5) Earbuds do not work as expected	5) Make sure you are wearing the earbuds correctly and check the battery level of the earbuds and the charging case.

Warning:

- 1 Please follow the instructions to operate.
- 2 Please don't use the earbuds in extreme temperatures.
- 3 Please don't use the product near water.
- 4 Please keep the product away from heat sources, as this could cause damage.
- 5 Don't use the ports such as charging port, LED port, etc.
- 6 It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the use basic service life.

Attention: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are used/held at high. This can be done by using the phone's media device.