



Airdopes 175 True Wireless Ear-buds


Get ready to immerse yourself in musical bliss with your very own pair of boat Airdopes 175. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual. Also, you may refer to the same at times when you face any sort of difficulty.

Package Contents

- 1x boat Airdopes 175
- 1x Charging Case
- 1x Type-C Charging Cable
- 2x Pairs of Additional Earbuds (Small & Large)
- 1x User Manual
- 1x Warranty Card
- 1x Catalogue
- 1x Head Set Card
- 1x FAQ Card

Overview

- CTC (Capacitive Touch Control) / Power Button



Power On:

Step 1: To switch the earbuds on, Smart Power-On simply opens the lid of the charging case (when earbuds are inside). Coupled with BT™ TrueWireless 3.0 Plus technology, the earbuds power on automatically, get connected and enter the connection stage.

OR

Step 2: After powering on, the earbuds enter the Connection Mode, indicated by alternate red and blue LED flashes on every earbud.

Connection Mode:

Step 3: Turn on the Bluetooth functionality on your phone/tablet device & scan.

Step 4: Search for Airdopes 175 and pair accordingly.


Congratulations! Your earbuds are now connected successfully via Bluetooth.

Note:

- Pairing may take up to 3 minutes. After pairing this is finished, there will be no need to reconnect the earbuds and they will perform automatic operations.
- Airdopes 175 movement (manually) connected devices, once connected, the earbuds automatically connect to the previously connected device in standby listening range.



Quick Guide on Functionalities



Single Earbud Usage

Step 1: These earbuds (both the earbuds) can be used in stereo mode. Use Smart Power-On for switching on the selected earbud.

Step 2: The selected earbud automatically enters the connection mode (indicated by LED flashes).

Step 3: Use the Bluetooth on your smartphone device and search for Airdopes 175 to connect.

Note:

- Connect the stereo mode, single side use. After selected from the case, there is approximately power on and pair with the previously selected earbud. There is no double connection.
- The selected side mode is return to the previous mode in Mono (single earbud) mode.



Charge the Earbuds:

Step 1: Please insert the earbuds back inside the charging case. In correct orientation.

Step 2: During charging, the indicator on the earbuds, turns red/red.

Step 3: Once the earbuds get fully charged, the charging case automatically switches off the power source, and the indicator indicates turn-off.

Note:

- Before using the earbuds for the first time, it is recommended to fully charge the earbuds. Also, please keep the lid of the charging case closed while charging.

Warning:

- Do not use the earbuds for a long time. It is recommended to fully charge the earbuds. Also, please keep the lid of the charging case closed while charging.

Charge The Case:

Step 1: To charge the case, plug one end of the provided charging cable into the case and connect the other end to a computer, wall adapter, powerbank, etc.

Note:

- While LED flashes while the case is in charging. When the case gets fully charged, it gets indicated by red LED.



Basic Functions:

• **Wake Up/Standby:** Long touch either CTC for 3 seconds to activate the wake-sleep mode.

• **Answer/Single Tap:** Tap the CTC on either earbud to answer an incoming call.

• **Hang Up/End Call:** Double tap the CTC on either earbuds end / repeat call.

• **Play/Pause Music:** Single tap either earbud's CTC to play or pause music.

• **Next Track:** When playing music, double tap the right earbud's CTC to skip to the next song.

• **Previous Track:** When playing music, double tap the left earbud's CTC to return to the previous song.

Note:

- Volume can only be controlled via the mobile phone.



Voice Assistant:

Step 1: Long touch the CTC on either earbud for 3 seconds to activate your phone's default smart voice assistant.

Step 2: The respective voice assistant screen pops up and you may place your commands at ease.

Note:


- This feature is available only on Android devices.

Tips: You may try the following commands:

- What is the weather?
- Play a song
- Set reminder

Note:

- If the earbuds are not connected to the mobile phone, the functionality has to be first enabled in your mobile phone settings.



ENx™ Tech

Our ENx™ tech algorithm cancels out the background noise so that you can be heard crystal clear in every call. One needed as ENx™ as the mics are not good with the noise and automatically cancel.

Note:

- For better voice with out background noise, use ENx™, which reduces delays, wait space thereby improving.

Smart Power Off

Step 1: After usage, move both the earbuds from your ears.

Step 2: Place the earbuds back into the charging case in correct orientation and close the lid.

The earbuds automatically switch off and enter charging mode.

Note:

- The earbuds automatically switch off and enter charging mode.

Manual Power Off

Step 1: Long touch CTC on each earbud separately for 3 seconds to manually power off the earbuds.

Step 2: Once the earbuds get turned off, place them back inside the case and close the lid.

Factory Reset:

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 175.

Note:

- *NOTE: Before performing reset, close 'Airdopes 175' from pairing device history by forgetting device.


Step 1: Take out both the earbuds from the case.

Step 2: Simultaneously, long touch CTC on both the earbuds for 5 seconds.

Step 3: Place the earbuds inside the case, close the lid and wait for 5 seconds.

Step 4: Take out the earbuds from the case and perform a fresh connection.

Congratulations! Your Airdopes 175 has been Reset.



Specifications

Headphone Type	TWS
Bluetooth Version	5.2
Music Playback	Up to 4096 per channel, up to 161945 additional with Case (at 80% volume)
ENx™ Tech Equipped Mic	4
Transmission Range	10m
Driver Size	10mm
Bluetooth Profiles	A2DP, AVRCP, HFP, HSP, GATT, LE, LEPP, LEAP, LEAP2, LEAP3
Frequency	20KHz - 20KHz
Battery	40mAh (earbuds) / 300mAh (Case)
Charging Time	1.5h (earbuds) / 2h (Case)
Charging Interface	USB Type C
Water Resistance	IP54

Charging Items & Precautionary Guidelines:

- 1) Charge While Waking: ON / OFF
- 2) Capacity: 40mAh (Earbuds) / 300mAh (Aluminum Case)

Any other accessories can be paired up with this product as long as the specifications are as per device norms.

Troubleshooting

Potential Problem	Solution
1) Intermittent connection	• Make sure you are close to the device
2) Earbuds do not work in stereo mode	• Make sure you have selected the correct mode in the app
3) Earbuds do not charge properly	• Make sure the earbuds are in the charging case and the case is fully charged
4) Earbuds do not connect to the phone	• Make sure the earbuds are in pairing mode and the phone is in Bluetooth mode

Warning:

- Please follow the instructions to operate.
- Please don't use the earbuds in extreme temperatures.
- Please don't use the product once water.
- Please keep the product away from heat sources, as this may lead to damage it.
- Don't use the ports such as charging, LED port, etc.
- It is recommended to take the product below the maximum volume in order to protect hearing and extend the use basic service life.

Note: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are used for long periods. This can be done by using the phone / remote device.