




**Noise Got
No Chance**
**USER
MANUAL**

Airdopes 70iANC
True Wireless Ear-Buds

Get ready to immerse yourself in musical bliss with your very own pair of boat Airdopes 70iANC. Please consider this manual as your guiding map towards the unparalleled shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual; also, you may refer to the same at times when you face any sort of difficulty in future.

- Package Contents**
- 1x Pair of TWS Earbuds
 - 1x Charging Case
 - 2x Pairs of Additional Earmuffs
 - 1x Type-C Charging Cable
 - 1x User Manual
 - 1x Warranty Card
 - 1x Catalogue



Power On (First Time User)

Step 1: To switch the earbuds on (Smart Power On) simply open the lid of the charging case (when earbuds are inside). Our IWP™ (Insta Wake N' Pair) Technology enables the earbuds to power on automatically, get connected and enter into the connection mode.

OR
Long touch the CTC (Capacitive Touch Control) on both earbuds for 3 seconds to manually power on the earbuds.

Step 2: Both the earbuds will automatically pair with each other. The earbuds will enter into the Connection Mode, indicated by 3 flashes of green LED.

Note: CTC (Capacitive Touch Control)

Connection Mode
Step 3: Turn on the Bluetooth functionality on your phone/media device and scan.

Step 4: Search for 'Airdopes 70iANC' & pair accordingly. Congratulations! Your earbuds are now successfully connected via Bluetooth.

Note:
• Pairing mode lasts for 5 minutes. If the pairing time is missed then you will need to reconnect the ear-buds and follow the above mentioned procedure.

• Airdopes 70iANC remembers previously connected devices; once switched on, the ear-buds automatically reconnect to the previously connected devices.



Single Earbud Usage

Step 1: Please note that both the earbuds can be used in mono mode. Use Smart Power On or Manual Power On for switching on the desired earbud


Step 2: The selected earbud will automatically enter the connection mode indicated by green LED flashes
Step 3: Turn on Bluetooth on your phone/media device and search for 'Airdopes 70iANC' to connect

Note:
• To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage
• You cannot skip tracks or return to the previous tracks in Mono mode



LED Indicators / Functionalities

- 3 Seconds** Long touch left earbud CTC for 3 seconds then release to activate voice assistant
- 3 Seconds** Manual Power ON: Long touch both CTCs for 3 seconds to manually power on
- 8 Seconds** Manual Power OFF: Long touch either CTC for 8 seconds to manually power off
- 10 Seconds** Factory Reset: Long press left and right earbuds' CTC for 10 seconds after power off.



Charging the Earbuds

Step 1: Please insert the earbuds back inside the charging case in correct orientation.

Step 2: A solid green LED indicates that the earbuds are being charged. Once fully charged the LED turns off

Step 3: Once the earbuds are fully charged, the charging case automatically switches off to save power.
Note:
• Before using the ear-buds for the first time, it is recommended to fully charge the ear-buds. Also, please keep the lid of the charging case closed while charging
• When the earbuds are in low power, slowly flashing green LED indicates the same

Charging the Case
Step 1: To charge the case, plug one end of the provided cable into the case and connect the other end to a computer/ wall adapter/ powerbank, etc. The case LED turns into solid red during charging and once fully charged the LED turns off

CASE LED Indication				
	No Earbuds in case	Left Earbud in case	Right Earbud in case	Both Left & Right earbuds in case
the case not in charging state	Light off	Green	Dark Blue	Sky Blue
	Light off	Light off (Earbuds fully charged)	Light off (Earbuds fully charged)	Light off (Earbuds fully charged)
The case in charging state	Red	Yellow	Purple	White
	Light off (Case fully charged)	Light off (both earbuds & case fully charged)	Light off (both earbuds & case fully charged)	Light off (both earbuds & case fully charged)

Note: The LED lights located on the charging case indicate the battery status of the case.

Basic Functions

• Active Noise Cancellation: Long touch right CTC for 3 seconds then release to switch from Standard to ANC mode
Note: CTC (Capacitive Touch Control)

• Ambient Sound Mode (Crystal mode): Long touch right CTC for 3 seconds then release again to switch from ANC mode to Ambient (Crystal) Mode.

• Beast mode (Gaming mode): Long touch the right CTC for 3 seconds then release to switch from Crystal Mode to BEAST (Gaming) Mode.

• Standard Mode: To go back to standard mode, long touch the right CTC for 3 seconds then release.

• Voice Assistant: Long touch the CTC on left earbud for 3 seconds then release to activate the voice assistant

• Answer: Single tap the CTC on either earbud to answer an incoming call

• Reject Call/Hang Up Call: Double tap the CTC on either earbud for Hanging Up a Call or Rejecting one

• Play/Pause Music: Single tap the CTC on either earbud

• Next Track: When playing music, double tap the right CTC to skip to the next song

• Previous Track: When playing music, double tap the left CTC to return to the previous song

Voice Assistant

Step 1: Long touch the CTC on left earbud for 3 seconds then release to activate the smart voice assistant

Step 2: The respective voice assistant screen pops up and you may place your commands at ease

Tips: You may try out the following commands,
• What is the weather?
• Play a song
• Set a reminder



Smart Power Off

Step 1: After usage, remove both the earbuds from your ears then release to activate the smart power off


Step 2: Place the earbuds back into the charging case in correct orientation

Step 3: The earbuds will automatically switch off (and enter into charging mode)

Manual Power Off

Step 1: Long touch the CTC on both earbuds for 8 seconds then release to manually power off after green LED flashes 3 times

Step 2: Once the earbuds get turned off, place them back inside the case and close the lid



Factory Reset

Perform the Factory Reset in case you face any difficulty while operating your Airdopes 70iANC

*NOTE: Before performing reset, clear "Airdopes 70iANC" from pairing device history by forgetting device

Actions have to be performed together on both earbuds outside the case


Step 1: Turn off both the earbuds by manual power off.

Step 2: Long Touch CTC on both the earbuds for up to 10 seconds to perform reset, indicated by green LED blinking three times

Step 3: Keep the earbuds back inside the case and shut the lid

Step 4: Reopen the lid and follow the aforementioned pairing procedure

Congratulations! Your Airdopes 70iANC has been Reset



Note: CTC (Capacitive Touch Control)

Troubleshooting

Potential Problem	Solution
If one earbud is not working	Perform the Factory Reset
If earbuds are not in connection/scan mode	Perform the Factory Reset
If earbuds disconnect during phone call	Charge the earbuds or perform the Factory Reset
If there are other exceptions in usage	Place the earbuds back into the charging case and try using them again or perform the Factory Reset
If the Touch Controls don't seem to respond	After long usage, residual stains & perspiration can affect the touch control area, please use a clean cloth to wipe softly

Advisable: The earbuds start at a 100% volume and it may need to be reduced when the earbuds are switched on at first. This can be done by using the volume control on the phone/ media device.

Charging norms & Precautionary Guidelines:

1) Charger/Brick/Adapter	: 5V/2A
1) Cable/Wire	: Standard Cable (15 Strands @0.10mm diameter/strand)

Any other accessory can be paired up with the product as long as the specifications are as per above norms.

Specifications

Headphone Type	: ANC TWS Earbuds
Bluetooth Version	: V5.0
Water Resistance	: IPX7
IWP Technology	: Yes
ANC	: Hybrid ANC (Up to 30dB)
Dual Microphones	: Yes
Music Playtime	: Up to 5.5H per charge; Up to 22H additional with Case
Charging Technology	: ASAP Fast Charge
Transmission Range	: 15m
Driver Size	: 9mm*2
Bluetooth Profiles	: HFP/ HSP/ A2DP/ AVRCP
Frequency	: 20HZ-20KHZ
Battery	: 550mAh (Case) 50mAh*2 (Earbuds)
Charging Time	: 1.5- 2 hours
Charging Interface	: Type C

Warning

- Please follow the instructions to operate
- Please don't use the ear-buds in extreme temperatures
- Please don't use the product near water
- Please keep the product away from heat sources, as the heat may damage it
- Don't jam the ports such as charger port, LED port, etc.
- It is recommended to utilize the product below the maximum volume in order to protect hearing and extend the ear-buds' service life

Advisable: The earbuds may start at a 100% volume and it may need to be reduced when they are switched on at first. This can be done by using the volume controls in the phone / media device