



boAt
plug into nirvana


102
Wireless Headset

User Manual

Thank you for choosing the boAt 102 Wireless. This manual is meant to guide you through to the shores of Nirvana without too much difficulty. Please think of this manual as your map. Knowledge of Bluetooth and device connection is essential for the steering of this boAt. Therefore, we strongly advise that this manual is thoroughly read before beginning use, and referred to when in times of difficulty.

Package Contents

1. boAt 102 Wireless x 1
2. User Manual x 1
3. Extra Eartips: S/L x 1
4. Micro USB-Cable x 1
5. Warranty Card x 1



Components

1. ABS front and back cavity
2. Volume down/Previous track
3. Multifunction Button
4. Volume up/Next track
5. Neckband
6. Charge port
7. Built in Mic

Functions

- (1) Power on: When switched off, press & hold the multifunction button for 2 seconds. A voice prompt will confirm the same. The red & blue LEDs will flash for 1 second.
- (2) Power off: In any mode, press and hold the multifunction button for 3 seconds. A voice prompt will confirm the same. The red and blue LEDs will flash for 1 second before the device turns off.
- (3) Play/Pause: Tap the multifunction button once to play/pause music.
- (4) Volume up: Tap the volume "+" button in steps to increase the volume. A beep will indicate maximum volume.
- (5) Volume down: Tap the volume "-" button in steps to decrease the volume. A beep will indicate minimum volume.
- (6) Answer/End call: Tap the multifunction button once when answering or ending a call to complete the action.
- (7) Reject call: Press and hold the multifunction button for 2 seconds when receiving a call to reject it. A beep will indicate this.
- (8) Previous Track: To go to the previous track, press and hold the "-" button for 2 seconds.
- (9) Next Track: To skip to the next track, press and hold the "+" button for 2 seconds.
- (10) Voice Assistant: Long press the MFB for up to 2 seconds to activate voice assistant
- (11) Clear paired device: Press and hold the volume buttons together for 5 seconds to reset the list of devices the earphones have been connected with. The red and blue lights flash thrice simultaneously.
- (12) Dual Pairing: To connect boAt 102 Wireless to two devices simultaneously, firstly connect the earphone to one of the devices. Then, switch both the earphone and the device off. Thereafter, connect the earphone to the second device, and again switch the first device on. The earphone will get connected to both devices. If not, connect the first device manually once again to activate dual pairing.

To Pair with Bluetooth

- (1) When switched off, press the multifunction button for 5 seconds to switch the earphones on. The earphones will automatically enter pairing mode with a prompt and the LED light will flash red and blue to indicate this.
- (2) Open Bluetooth on your device and search for "102 Wireless" in the list of available devices.
- (3) Choose "102 Wireless" from the list and if asked for, enter the pairing password "0000" to establish Bluetooth connectivity. A voice prompt "connected" will be heard to confirm the connection. The blue LED flashes twice every 4 seconds while it is being connected.
- (4) If the pairing fails, the blue LED flashes once every 2 seconds. The earphone will automatically shut down if not paired within 5 minutes of being on.

To Charge

- Use a micro USB charging cable to charge the earphone.
- (1) Low Battery: The remaining talk time is less than 10 minutes. There will be a 'tone' and a reminder every minute.
 - (2) Charging: The red LED stays steady (please note that the earphone cannot be turned on when charging).
 - (3) Fully charged: The blue LED stays steady.

Specifications

- Sensitivity: 104±3dB
- Impedance : 16 Ω
- Frequency response: 20-20KHz
- Driver size: 8mm
- Neckband length: 300mm
- Cord length: 250mm
- Bluetooth version: V5.0
- Battery: Lithium-ion battery(VDL460942)/3.7V/160mAh
- Charging time: About 2.5 hours
- Music/Play/Talking time: Up to 15 hours
- Standby time: about 320 hours
- Transmission range: about 10m
- Support agreement: HSP/ HFP/ AVRCP/A2DP
- Water Resistance: IPX4
- Dual Pairing: Yes

Safety Cautions

- Please don't dismantle the product in any way, as this can lead to a fire or electrical breakdown and completely damage the product. As this is extremely unsafe, we ask that any maintenance or servicing of the earphones is done only through a qualified service provider/manufacturer.
- Please do not remove the battery by yourself, this is a task meant to be managed by a service provider/manufacturer. Replacing the current battery with an ill-fitting set can result in a fire or electric hazard, therefore it is strongly advised against.
- Please clean the earphones with the utmost of care with only a damp soft cloth, if cleaning is required. Please do not use any oily volatile liquid. In addition, ensure that the earphones are kept away from extremely hot or cold substances.
- Any damage to the earphones that is NOT a manufacturing issue will make the products warranty null and void. Please take the greatest care of your earphones to ensure that no such occurrences take place.
- Do not use earphones when it is unsafe to be wearing them, such as while operating a vehicle, crossing a street, or during any activity where full awareness of your surroundings is required. This is because it is dangerous to drive while wearing earphones as it decreases your ability to hear sounds like another car's horn or an emergency vehicle's sirens.
- To avoid damage to your hearing, make sure that the volume on your music player is at an appropriate level when you are Plugging into Nirvana. After wearing the earphones, gradually turn up the volume until you reach a comfortable listening level. Exposure to any noise levels at or above 85 dB can gradually lead to a loss of hearing.

Dual Pairing:

To connect 102 Wireless to two devices simultaneously, firstly connect the earphone to one of the devices. Then, switch both the earphone and the device off. Thereafter, connect the earphone to the second device, and again switch the first device on. The earphone will get connected to both devices. If not, connect the first device manually once again to activate dual pairing.

Charging norms & Precautionary Guidelines: -	
1) Charger/Brick/Adapter	: 5V 2A
2) Cable/Wire	: Standard Cable (35 strands @0.10mm diameter/ strand)
Any other accessory can be paired up with the product as long as the specifications are as per above norms.	

CONNECT WITH US ON

- boAt-lifestyle.com
- facebook.com/boat.nirvana
- instagram.com/boat.nirvana
- youtube.com/boAt-nirvana

boAt
plug into nirvana



102
Wireless Headset