


# User Guide

MadRabbit Sound Rock


# Specifications

---

Model :	MadRabbit Sound Rock
Bluetooth Version :	V 5.0
Bluetooth Range :	10 m
Frequency Range :	20 Hz - 20 KHz
Speaker Size :	52 mm
Output Power :	5 W
Battery Capacity :	1200 mAh
Play Time :	5 h at 60% volume
Charging Time :	3 h
Charging Interface :	Type-C
Waterproof :	IPX7
Support :	BT, TF



# Know Your Speaker



## Getting Started: Charging the Speaker

**Charge the speaker before use and keep the speaker off for faster charging.**

- Connect the end of Type C to the USB Charging Port of the speaker.
- Connect the standard USB Plug end of the cable to a powered USB port on a Desktop / Laptop or any 5V USB AC adaptor (not included).



The status indicator light will be solid Red when charging and will turn off once fully charged.


## Getting Started: Power ON / OFF

- Press 'POWER' Button for 1.5 secs to Power ON the Speaker.
- Press 'POWER' Button for 1.5 secs to Power OFF the Speaker.



## Bluetooth Pairing

Bluetooth pairing with Smartphone or Laptop for the first time.



Turn ON the MadRabbit Sound Rock speaker.

The status indicator light will be solid Red when charging and will turn off once fully charged.




Select 'MadRabbit Sound Rock'. It should appear in your device's Bluetooth menu.



When connected, the Blue LED indicator becomes stable.

Note 1: When the speaker is under Bluetooth mode, it will be connected to the last connected device by default. If you want to connect the speaker to another device you need to disconnect from the original device.


Note 2: Double-Click Power Button to disconnect device.

# Function

Button	Operating	Function Description
	Long Press	Turn ON / OFF: Long Press for 1.5 secs; Speaker Freeze Status: Long Press for 8 secs to reset.
	Short Press	Volume Down.
	Long Press	Previous Song: Long Press for 1.5 secs.
	Short Press	1. Music Playback Status: Short Press to Pause / Play; 2. Incoming Call Status: Short Press to Connect the Phone; 3. When Answering the Call: Short Press to Hang Up.

Button	Operating	Function Description
	Long Press	BT Pairing Status: Long Press for 2 secs to Disconnect the BT Connection; Incoming Call Status: Long Press for 3 secs to Reject the Call.
	Short Press	Volume Up.
	Long Press	Next Song: Long Press for 1.5 secs.

# TWS (Twin Speaker Pairing)



**Step 1:** Turn ON the Speaker 1 by pressing 'POWER' Button for 1.5 secs.

**Step 2:** Turn ON the TWS functionality of Speaker 1

Double click Power Button to Turn ON the TWS function of the Speaker

The speaker makes a 'double beep' sound with Blue indicator light flashing quickly, and the speaker opens to TWS function.

**Step 3:** Repeat Step 1 and 2 for Speaker 2.

If the connection is successful, the Blue indicator light of the connected speaker will flash slowly and the Blue indicator light of another speaker will turn on.

**Step 4:** Turn ON your Bluetooth device (Smartphone or Laptop) and connect with 'MadRabbit Sound Rock'

Double-Click Power Button to disconnect device.


# Micro SD Card Playback


---

Insert a Micro SD Card to start listening.

Single Press ( Volume  /  Button )  
for Volume Down / Up

Long Press ( Volume  /  Button )  
for Pre / Next Track.

Single Press ( Play / Pause  Button )  
to Pause the Speaker.



## Auto OFF

When the speaker is turned on and there is no connection or operation for 5 mins, the speaker will turn off automatically.

---

## Troubleshooting

### The speaker is not working?

Check if the speaker is turned on and the volume is adjusted properly.  
Make sure that the device is paired / cable connected and the music source volume is not muted.  
Make sure the speaker is charged.

---

## Can I use 'MadRabbit Sound Rock' while it is charging?

Yes, you can use your 'MadRabbit Sound Rock' while it is charging.

---

## Can I use FM Radio in 'MadRabbit Sound Rock'?

No, there is no in-built FM Radio in 'MadRabbit Sound Rock'

# Safety Information

---

Before using and operating the speaker, please read and follow the below precautions to ensure the best performance of it and to avoid dangerous or illegal situations.

## Electronic Devices

- Do not use this device in the place where wireless devices are prohibited, otherwise it will interfere with other electronic devices or cause other dangers.

## Medical Equipment Interference

- In medical and health care places where the usage of wireless devices is prohibited, please follow the rules and turn off the device.
- The radio waves generated by the device may affect the normal operation of implanted or personal medical devices, such as pacemakers, cochlear implants, speaker aids, etc. If you use these medical devices, please consult the manufacturer for restrictions on the use of this device.
- When using this device, kindly keep a distance of at least 15 cm from the implanted medical devices (such as pacemakers, cochlear implants, etc.)

## Hearing Loss

- Listening to sound at high volume may permanently damage your hearing. When you use speaker to listen to music or calls, it is recommended to use the minimum volume required to avoid hurting your hearing.
- Exposure to high-level volume while driving may distract the driver and cause accidents.

## Operating Environment

- Do not use the device in dusty, sharp, compact areas or near magnetic fields, etc., to avoid failure of the internal circuit of the device.
- When installing the device, please keep away from strong magnetic fields or electrical appliances with strong magnetic fields, such as ovens and refrigerators.
- Do not use the device in thunderstorm weather. Thunderstorm weather may cause equipment failure or electric shock hazard.
- Please use the device within a temperature range of  $-10^{\circ}\text{C} \sim +55^{\circ}\text{C}$ , and store the device and its accessories within a temperature range of  $-40^{\circ}\text{C} \sim +70^{\circ}\text{C}$ . When the ambient temperature is too high or too low, it may cause device function failure. When the temperature is below  $5^{\circ}\text{C}$ , the performance of the battery is limited.





# Safety Information

---

- Do not place the device in direct sunlight, such as the dashboard or window sill of a car.
- Do not place the device near heating sources or exposed fire sources, such as electric heaters, ovens, water heaters, stoves, candles, or other places that generate high temperatures.
- Do not place sharp metal objects such as pins near the device's earpiece or speaker, as the metal objects may adhere and cause injury to you.

## Child Health

- This device and its accessories may contain some small parts. Keep the device and its accessories in a place out of children's reach. Children may inadvertently damage the device and its accessories, or swallow small parts, causing suffocation or other hazards.
- This device is not a toy, children should use this device under adult supervision.

## Battery Safety

- Do not disassemble or modify the battery, or immerse in water or other liquids, to avoid battery leakage, fire or explosion.
- Do not drop, crush or puncture the battery. It can cause internal short circuits and overheating.
- This device is equipped with a non-removable built-in battery. Do not replace the battery yourself to avoid damage to the battery or device.
- Please dispose batteries in accordance with local regulations. Do not dispose batteries as household waste. Improper disposal of the battery may cause the battery to explode.

## Charge Safety

- When charging the device, the power socket should be installed near the device and should be easily accessible.
- When charging is completed or when charger not in use, disconnect the charger from the device and unplug the charger from the power outlet.

## Environmental Protection

- Do not dispose this device and its accessories as ordinary household garbage.
- Kindly abide by the local laws and regulations on the handling of this device and its accessories, and support recycling operations.



# Trademarks

---

MadRabbit word mark and logo are registered trademarks of Redster Commerce Pvt. Ltd. Reproduction in whole or in part without written permission is strictly prohibited. Other companies and products mentioned herein are trademarks of their respective owners.

Made in China.

## MadRabbit Warranty

---

- The device is guaranteed for 12 months from the date of purchase. Repair and maintenance service are free during this period.
- The warranty limitation:
  - Man-made damage.
  - Beyond the warranty period.
  - Accessories damage due to improper use and maintenance.
  - Disassembling the device without the authority of the manufacturer.
- Service Information
  - MadRabbit Website : <https://www.madrabbit.in>



TM



Scan To Register A Warranty



Scan To Register A Warranty